

Price with VAT£7.31

Price ex VAT£7.31 Tax amount

Silca TOY40 Toyota Lexus 2 Button Replacement Key Shell TOY40BRS2 Toyota Lexus Celsior, ES300, Land Cruiser, LS400, LX450, LX470, SC300/400, Century and Land Cruiser 100

Description

Silca TOY40 Toyota Lexus 2 Button Replacement Key Shell TOY40BRS2

This key is listed for use with the vehicles listed below.

Lexus

- .Celsior (Japan) (1997 2000)
- ES300 (1998 2001)
- Land Cruiser (Japan) (1999 On)
- .LS400 (1997 2000)
- LX450 (1998 2002)
- .LX470 (1999 2000)
- .SC300/400 (1998 2003)

Toyota

- .Century (1998 On)
- .Land Cruiser 100 (1998 2000)

Please note this is guidance only, if you are not sure, please contact us

Replacement Car Key Shell, transfer internal electrics from old key to new. Please note this key is not supplied with any chips or transponders

Suitable for					
Toyota Lexus					
Model	Fro m	То			
Celsior	19 97	20 00			
ES300	19 98	20 01			
Land	19				

Cruiser	99		
LS400	19	20	
	97	00	
LX450	19		
	98		
LX470	19	20	
	99	00	
SC300/40	19	20	
0	98	03	
Century	19		
	98		
Land	19	20	
Cruiser	98	00	
100			

Key			
Cutting			
Series			
0001-5000			
L0001-L10			
00			
G0001-G2			
500			
J0001-J25			
00			
K0001-K25			
00			
P0001-P25			
00			
30001-312			
00			

If you have a key number that falls into the above range and would like your key cut, please add your key number to the Key Code box below.

Please note we can not accept returns for any cut keys