

Price with VAT£7.31

Price ex VAT£7.31 Tax amount

Silca TOY40 Toyota Lexus 3 Button Replacement Key Shell TOY40BRS8 for Toyota Lexus Celsoir, ES300, Land Cruiser, LS400, LX450, LX470, SC300/400, Century, Land Cruiser 100 and Tarago

## Description

Silca TOY40 Toyota Lexus 3 Button Replacement Key Shell TOY40BRS8

This key is listed for use with the vehicles listed below.

Lexus

.Celsior (Japan) (1997 - 2000) .ES300 (1998 - 2001) .Land Cruiser (Japan) (1999 - On) .LS400 (1997 - 2000) .LX450 (1998 - 2002) .LX470 (1999 - 2000) .SC300/400 (1998 - 2003)

## Toyota

.Century (1998 - On) .Land Cruiser 100 (1998 - 2000) .Tarago (1995 - 1998)

Please note this is guidance only, if you are not sure, please contact us

Replacement Car Key Shell, transfer internal electrics from old key to new. Please note this key is not supplied with any chips or transponders.

Suitable for			
Тоу	ota		
Model	Fro m	То	
Celsior	19 97	20 00	

	40	
ES300	-	20
	98	01
Land	19	
Cruiser	99	
LS400	19	20
	97	00
LX450	19	
	98	
LX470	19	20
	99	00
SC300/40	19	20
0	98	03
0 Century	19	20
	98	05
Land	19	20
Cruiser	98	00
100		
Tarago	19	19
-	95	98

Кеу		
Cutting		
Series		
0001-5000		
L0001-L10		
00		
G0001-G2		
500		
J0001-J25		
00		
K0001-K25		
00		
P0001-P25		
00		
30001-312		
00		

If you have a key number that falls into the above range and would like your key cut, please add your key number to the Key Code box below.

Please note we can not accept returns for any cut keys