

Price with VAT£7.31

Price ex VAT£7.31 Tax amount

Silca TOY40 Toyota Lexus 3 Button Replacement Key Shell TOY40BRS8 for Toyota Lexus Celsoir, ES300, Land Cruiser, LS400, LX450, LX470, SC300/400, Century, Land Cruiser 100 and Tarago

Description

Silca TOY40 Toyota Lexus 3 Button Replacement Key Shell TOY40BRS8

This key is listed for use with the vehicles listed below.

Lexus

- .Celsior (Japan) (1997 2000)
- ES300 (1998 2001)
- .Land Cruiser (Japan) (1999 On)
- .LS400 (1997 2000)
- LX450 (1998 2002)
- .LX470 (1999 2000)
- .SC300/400 (1998 2003)

Toyota

- .Century (1998 On)
- .Land Cruiser 100 (1998 2000)
- .Tarago (1995 1998)

Please note this is guidance only, if you are not sure, please contact us

Replacement Car Key Shell, transfer internal electrics from old key to new. Please note this key is not supplied with any chips or transponders.

Suitable for				
Toyota				
Model	Fro m	То		
Celsior	19 97	20 00		

ES300	19	20	
	98	01	
Land	19		
Cruiser	99		
LS400	19	20	
	97	00	
LX450	19		
	98		
LX470	19	20	
	99	00	
SC300/40	19	20	
0	98	03	
0 Century	19	20	
	98	05	
Land	19	20	
Cruiser	98	00	
100			
Tarago	19	19	
	95	98	

Key Cutting Series 0001-5000 L0001-L10 00 G0001-G2 500 J0001-J25 00 K0001-K25 00 P0001-P25 00 30001-312

00
30001-312
00
If you have a key number that falls into the above range and would like your key cut, please add your key number to the Key Code box below.

Please note we can not accept returns for any cut keys